

Add more Do more

With John Deere 5M Tractor attachments



Hood Guard

Protects your tractor's grill and radiator from brush and workplace hazards.

BW15657 Hood guard 553, 563, 673 loaders
BW16009 Hood guard H240, H260, H310 loaders



Loader Light Kits

Additional work lights increase illumination and productivity when working at night or early morning.

LVB24997 Auxiliary loader lights
LVB25720 Auxiliary work light kit (2 lights)



Rear Fender Extension

Helps protect operator, tractor, and implements by reducing the amount of material thrown off the rear tires.

LVB25714



Telescopic Mirrors

Provide wide rear view of the field or road. Especially useful when towing wagons or large implements.

AL80126 Left-hand mirror
AL80127 Right-hand mirror



Rear Wheel Weight

Get more traction for the job at hand.

R213907 95-lb. rear wheel weight

BUY NOW, PAY LATER

When you put it on your multi-use account.
 Ask us for details!*



Stationary Front Fenders

Large, full-coverage, durable rubber fenders protect operator stations from mud and debris.

BW16094

*Talk to us today about how attachments can **Add More** to your tractor experience.*



Protect your equipment

With John Deere filters

5085M / 5100M / 5100MH / 5115M / 5115ML IT4 TRACTORS

Hydraulic Filter




Cab Air Filters – 2



Fuel Filters



Engine Oil Filter



Engine Air Filter

1 Hydraulic Filter

Designed to protect hydraulic systems from component wear and surge flow. Replace every 600 hours.

SJ11784

2 Cab Air Filters — 2

Keep inside cab air fresh and flowing, and dust and pesticide vapors outside. Clean every 600 hours or annually — as required per conditions.

RE198488 Fresh air
RE195491 Recirculation air

3 Fuel Filters

Designed to trap and repel water — fuel's number one enemy. Prevent rust and microbial growth that can damage fuel and lead to poor fuel economy. Replace every 500 hours.

RE541922 Primary
RE544394 Final

4 Engine Air Filter

Highly efficient filters reduce engine wear by removing rust, dirt and other pollutants from intake air. Replace primary element every 1,200 hours or annually as required by conditions.

SU20768 Primary
RE253519 Secondary

5 Engine Oil Filter

Superior protection with rubber gaskets that resist decomposition. Replace every 300 hours. If using Plus-50™ II, interval can be increased to 500 hours.

RE504836

Don't forget the recommended John Deere fluids for your machine!

